


Music Stand Upper Rail



SECTION REFERENCE
(NO SCALE)

1	<i>NOTE: Pattern is full scale. One square = 1". Set printer options to "actual size" or 100% for best results</i>		
2			
3			
4	<i>SECTION 1</i>		
5			
6			
7			
8			

8				
9				
10				
11	<i>SECTION 2</i>			
12				
13				
14				
15				
16				
17				

16					
17					
18	<i>SECTION 3</i>				
19					
20					
21					
22					
23					
24					